



CATALOGUE 2026

21.12.2025

O.E.M.code	TAURUS code	Description
1801001	T-A87102660	Air Filter
1801006	T-A87102860	Air Filter
1801010	T-A878960	Air Filter
1801012	T-A8712260	Air Filter
1801013	T-A8765160	Air Filter
1801014	T-A879660	Air Filter
1801015	T-A8712060	Air Filter
1801017	T-A879160	Air Filter
1801025	T-A87105360	Air Filter
1801029	T-A879560	Air Filter
1801032	T-FS532302-HQ	Air-Oil Separator Iron end caps
1801033	T-FS532303-HQ	Air-Oil Separator Iron end caps
1801035	T-A87104560	Air Filter
1801036	T-A87102760	Air Filter
1801038	T-A879760	Air Filter
1801039	T-A87105460	Air Filter
1801040	T-A87106960	Air Filter
1801046	T-FS990200	Air-Oil Separator Plastic Version
1801049	T-A8711860	Air Filter
1801055	T-A87P09160	Air Filter
1801056	T-A87P12060	Air Filter
1801057	T-A87670	Air Filter
1801058	T-A87P65160	Air Filter
1801059	T-A8794360	Air Filter
1801060	T-A8789960	Air Filter
1801061	T-A877560	Air Filter
1801062	T-A872560	Air Filter
1801063	T-FS532304-HQ	Air-Oil Separator Iron end caps
1801073	T-FS990065	Air-Oil Separator
1802024	T-A87170 ³	Air Filter
1809001	T-FO531002	Oil Filter
1809002	T-FO531001	Oil Filter
3301002	3301002	Vane
3301011	3301011	Vane
3301012	3301012	Vane
3301016	3301016	Vane
3301018	3301018	Vane
3301020	3301020	Vane
3301021	3301021	Vane
3301027	3301027	Vane
3302029	3302029	Vane
3302033	3302033	Vane
3302034	3302034	Vane
3302035	3302035	Vane
3302038	3302038	Vane
3302040	3302040	Vane
3302042	3302042	Vane
3302047	3302047	Vane
3302048	3302048	Vane
3302054	3302054	Vane



CATALOGUE 2026

21.12.2025

9001017	T-FCV104	Air Filter Housing
9001018	T-FCV107	Air Filter Housing
9001019	T-FCV108	Air Filter Housing
9001022	T-FCV105	Air Filter Housing
9001024	T-FCV103	Air Filter Housing
9001025	T-FCV102	Air Filter Housing
9001040	T-FCV109	Air Filter Housing
9001041	T-FCV111	Air Filter Housing
9001042	T-FCV112	Air Filter Housing
9001050	T-B1	Oil bath Air Filter
9001051	T-B2	Oil bath Air Filter
9001052	T-B3	Oil bath Air Filter
9001053	T-B4	Oil bath Air Filter
9001058	T-FB21	Air Filter Housing
9001060	T-FB23	Air Filter Housing
9001061	T-FB24	Air Filter Housing
9001062	T-FB25	Air Filter Housing
9001077	T-FCV203	Air Filter Housing
9001078	T-FCV202	Air Filter Housing
9001079	T-FCV205	Air Filter Housing
9001080	T-FCV204	Air Filter Housing
9001081	T-FCV207	Air Filter Housing
9001082	T-FCV208	Air Filter Housing
9001083	T-FCV209	Air Filter Housing
9001084	T-FCV211	Air Filter Housing
9001085	T-FCV212	Air Filter Housing
9001086	T-FB27	Air Filter Housing
9001087	T-FCV114	Air Filter Housing
9409000	T-SS12	Silencer two connections
9409001	T-SS13	Silencer two connections
9409002	T-SS14	Silencer two connections
9409003	T-SS15	Silencer two connections
9409004	T-SS16	Silencer two connections
9409005	T-SS18	Silencer two connections
9409010	T-SS3	Silencer one connections
9409011	T-SS4	Silencer one connections
9409012	T-SS5	Silencer one connections
9409013	T-SS6	Silencer one connections
9409014	T-SS7	Silencer one connections
9409015	T-SS9	Silencer one connections
9603021	T-FS990060	Air-Oil Separator
9603021	T-FS990122	Air-Oil Separator
0307001	T-Z9053	Gasket
1001053/V	T-Z5626	Gasket
1801037	T-A87102960	Air Filter
1801072	T-FSP10910	Air-Oil Separator
1801075	T-FS990058	Air-Oil Separator
1801076	T-FS532303-HQ	Air-Oil Separator Iron end caps
1801080	T-FS532302-HQ	Air-Oil Separator Iron end caps
1801081	T-FS532304-HQ	Air-Oil Separator Iron end caps
1801082	T-FS990200	Air-Oil Separator Plastic Version



CATALOGUE 2026

21.12.2025

1801083	T-FSP10910	Air-Oil Separator
1801095	T-FS990065	Air-Oil Separator
1801096	T-FS990058	Air-Oil Separator
4604053	T-Z9050	Check valve
4901044	T-Z9051	Gasket
4901057	T-Z9052	ORIGINAL Gasket
4901078	T-Z9062	Gasket LC.106/151 p.69
9001033	T-FS990058	Air-Oil Separator
9001046	T-FSP10910	Air-Oil Separator
SAD.1	T-SS12	Silencer two connections
SAD1	T-SS12	Silencer two connections
SAD1-1/2	T-SS14	Silencer two connections
SAD1-1/4	T-SS13	Silencer two connections
SAD2	T-SS15	Silencer two connections
SAD2-1/2	T-SS16	Silencer two connections
SAD4	T-SS18	Silencer two connections
SAS.2-1/2	T-SS7	Silencer one connections
SAS1	T-SS3	Silencer one connections
SAS1-1/2	T-SS5	Silencer one connections
SAS1-1/4	T-SS4	Silencer one connections
SAS2	T-SS6	Silencer one connections
SAS2-1/2	T-SS7	Silencer one connections
SAS4	T-SS8	Silencer one connections