



CATALOGUE 2026

21.12.2025

O.E.M.code	TAURUS code	Description
732	T-FS3020	Air-Oil Separator
9363	T-A872760	Air Filter
516533	T-FS3020	Air-Oil Separator
9202901	T-A872260	Air Filter
32170979	T-A8789360	Air Filter
36762250	T-FS17320	Air-Oil Separator
39856844	T-FO3218380	Oil Filter
39863873	T-FS19920	Air-Oil Separator
39863899	T-FS19920	Air-Oil Separator
39900923	T-FS24220	Air-Oil Separator
39903281	T-A8787060	Air Filter
88181763	T-FS18320	Air-Oil Separator
88200753	T-FS11520	Air-Oil Separator
88204318	T-FS24220	Air-Oil Separator
88210620	T-A8784760	Air Filter
88226220	T-A8793160	Air Filter
88281829	T-A8769660	Air Filter
89295976	T-A8793160	Air Filter
89298976	T-A87114860	Air Filter
93158624	T-A87119460	Air Filter
93158632	T-A872460	Air Filter
93501807	T-FS2720	Air-Oil Separator
93504231	T-FS3930	Air-Oil Separator
93505519	T-FS5910	Air-Oil Separator
93514529	T-FS3020	Air-Oil Separator
93515211	T-A8713560	Air Filter
93516342	T-FS8430	Air-Oil Separator
93520773	T-FS13420	Air-Oil Separator
93520781	T-FS10220	Air-Oil Separator
93520807	T-FS9020	Air-Oil Separator
93522902	T-FS3620	Air-Oil Separator
93523199	T-A872960	Air Filter
93523207	T-A8772160	Air Filter
93523215	T-FS5920	Air-Oil Separator
93525350	T-A876760	Air Filter
93525657	T-FS650	Air-Oil Separator
93568005	T-A876760	Air Filter
93568236	T-FO3210780	Hydraulic Filter
93568244	T-FS5910	Air-Oil Separator
93568251	T-FS2720	Air-Oil Separator
93568277	T-FS3930	Air-Oil Separator
93568285	T-FO3211980	Oil Filter
93568293	T-FS5920	Air-Oil Separator
93568301	T-FS3620	Air-Oil Separator
93568319	T-FS7530	Air-Oil Separator
93568343	T-FS3130	Air-Oil Separator
93578284	T-FO3211380	Oil Filter
93578334	T-A8772160	Air Filter
93578342	T-A872960	Air Filter
93578359	T-A876760	Air Filter

93578367	T-FO3210980	Oil Filter
93578383	T-FS10220	Air-Oil Separator
93580876	T-A8766260	Air Filter
93585123	T-A876460	Air Filter
93585297	T-FO3210880	Oil Filter
93585495	T-A8766360	Air Filter
93600344	T-FS2630	Air-Oil Separator
93600385	T-FS430	Air-Oil Separator
93600740	T-FS3130	Air-Oil Separator
93602803	T-A872360	Air Filter
93602894	T-A8715660	Air Filter
93603157	T-FO3211080	Oil Filter
93603223	T-A873360	Air Filter
93603355	T-A874260	Air Filter
93603413	T-A873160	Air Filter
93603496	T-FS1820	Air-Oil Separator
93604031	T-FS320	Air-Oil Separator
93604080	T-A87560	Air Filter
93604890	T-A8768060	Air Filter
93604908	T-A87460	Air Filter
93604965	T-FS5520	Air-Oil Separator
93605558	T-FS10220	Air-Oil Separator
93605632	T-A877060	Air Filter
93606234	T-A876860	Air Filter
93606390	T-FS7530	Air-Oil Separator
93611028	T-FS3420	Air-Oil Separator
93611069	T-FO3211980	Oil Filter
93612497	T-FS2110	Air-Oil Separator
93612794	T-FS14620	Air-Oil Separator
93612844	T-FS8420	Air-Oil Separator
93613107	T-FS450	Air-Oil Separator
93613172	T-A873360	Air Filter
93618171	T-FS920	Air-Oil Separator
93618270	T-FS1220	Air-Oil Separator
93618569	T-FS1820	Air-Oil Separator
93618718	T-FS3020	Air-Oil Separator
93618759	T-FS2720	Air-Oil Separator
93618767	T-A87560	Air Filter
93618858	T-FS620	Air-Oil Separator
93618866	T-A874260	Air Filter
93619898	T-FS13120	Air-Oil Separator
93620037	T-FS420	Air-Oil Separator
93620045	T-A872960	Air Filter
93621514	T-FS110	Air-Oil Separator
93621522	T-A874560	Air Filter
93622322	T-FO3215380	Oil Filter
93623759	T-FS2810	Air-Oil Separator
93627941	T-FS13120	Air-Oil Separator
93682516	T-FS2110	Air-Oil Separator
177534492	T-FS31210	Air-Oil Separator
400651042	T-FO3210780	Hydraulic Filter



CATALOGUE 2026

21.12.2025

400751062	T-A8714860	Air Filter
401151022	T-A877660	Air Filter
401951012	T-FS3520	Air-Oil Separator
402151012	T-FS2220	Air-Oil Separator
402351012	T-FS3420	Air-Oil Separator
402351082	T-FO3211980	Oil Filter
402851042	T-A873260	Air Filter
403351012	T-FS3620	Air-Oil Separator
404051022	T-A872960	Air Filter
404051032	T-A8772160	Air Filter
404051062	T-FS5920	Air-Oil Separator
406051012	T-FS2110	Air-Oil Separator
406051022	T-A876760	Air Filter
407051052	T-FS14620	Air-Oil Separator
407151032	T-FS8420	Air-Oil Separator
407151052	T-FS5520	Air-Oil Separator
410151022	T-FS550	Air-Oil Separator
410251012	T-FS650	Air-Oil Separator
410351022	T-FS450	Air-Oil Separator
410351032	T-FO531001	Oil Filter
410451022	T-A873360	Air Filter
410551022	T-A87460	Air Filter
410151052	T-FF5113	Fuel Filter
93578300	T-A872560	Air Filter
BK2253101	T-FS2630	Air-Oil Separator
BK2295900	T-FS430	Air-Oil Separator
BK22959430	T-FS430	Air-Oil Separator
BK3297202	T-FS3130	Air-Oil Separator
BK3712300	T-FS3930	Air-Oil Separator
BK3842400	T-FS5910	Air-Oil Separator
BN01371	T-A8714560	Air Filter
BN01817	T-A8715660	Air Filter
BN01886	T-A872360	Air Filter
BN02206	T-A873860	Air Filter
BN03029	T-A8766260	Air Filter
BN07088	T-FS2020	Air-Oil Separator
BN07537	T-FS1220	Air-Oil Separator
BN07698	T-A872360	Air Filter
BN08434	T-FO3211980	Oil Filter
BN08463	T-A873460	Air Filter
BN09003	T-FS2720	Air-Oil Separator
BN09656	T-A873360	Air Filter
BN10256	T-A874260	Air Filter
BN10334	T-A873160	Air Filter
BN10374	T-A8711660	Air Filter
BN10434	T-FS1820	Air-Oil Separator
BN14565	T-FS320	Air-Oil Separator
BN14687	T-A87560	Air Filter
BN15086	T-A872560	Air Filter
BN16013	T-FO3210980	Oil Filter
BN16273	T-FS2720	Air-Oil Separator

BN16533	T-FS3020	Air-Oil Separator
BN17534	T-A87460	Air Filter
BN17536	T-A87460	Air Filter
BN17756	T-FS5520	Air-Oil Separator
BN17912	T-A8713560	Air Filter
BN18480	T-FS5520	Air-Oil Separator
BN19767	T-FS9020	Air-Oil Separator
BN19940	T-FS8430	Air-Oil Separator
BN20062	T-FS9830	Air-Oil Separator
BN20292	T-A877060	Air Filter
BN20660	T-FS10220	Air-Oil Separator
BN20661	T-FS8920	Air-Oil Separator
BN20662	T-FS16720	Air-Oil Separator
BN20992	T-A877060	Air Filter
BN23573	T-FS5920	Air-Oil Separator
BN24857	T-FS13420	Air-Oil Separator
BN24858	T-FS10220	Air-Oil Separator
BN24859	T-FS8920	Air-Oil Separator
BN24860	T-FS9020	Air-Oil Separator
BN2639500	T-A876860	Air Filter
BN2785000	T-FS7530	Air-Oil Separator
CK4290-274	T-FS990015	Air-Oil Separator
CK432972	T-FS3130	Air-Oil Separator
CK437123	T-FS3930	Air-Oil Separator
DV750	T-FS2020	Air-Oil Separator
DV750	T-FS2720	Air-Oil Separator
E0410010	T-FS31210	Air-Oil Separator
F30	T-A873260	Air Filter
F401951042	T-A872260	Air Filter
F402151012	T-FS9920	Air-Oil Separator
F402351072	T-FO3211380	Oil Filter
K22531	T-FS2630	Air-Oil Separator
K22959	T-FS430	Air-Oil Separator
K32972	T-FS3130	Air-Oil Separator
KB22531430	T-FS920	Air-Oil Separator
KB22959430	T-FS430	Air-Oil Separator
N00070	T-A8712360	Air Filter
N01128	T-A872160	Air Filter
N01371	T-A8714560	Air Filter
N01817	T-A8715660	Air Filter
N01886	T-A872360	Air Filter
N02206	T-A873860	Air Filter
N07033	T-A8715760	Air Filter
N07088	T-FS2020	Air-Oil Separator
N07468	T-FS3020	Air-Oil Separator
N07537	T-FS1220	Air-Oil Separator
N07698	T-A872260	Air Filter
N08109	T-A877660	Air Filter
N08152	T-A8714960	Air Filter
N08176	T-A8714860	Air Filter
N08177	T-A8714760	Air Filter



CATALOGUE 2026

21.12.2025

N08463	T-A873460	Air Filter
N08464	T-A8715860	Air Filter
N08466	T-A8715160	Air Filter
N08567	T-A8715260	Air Filter
N08568	T-A8715960	Air Filter
N09003	T-FS2720	Air-Oil Separator
N09202	T-FO3211980	Oil Filter
N10119	T-A872460	Air Filter
N10434	T-FS1820	Air-Oil Separator
N13195	T-A872460	Air Filter
N14565	T-FS320	Air-Oil Separator
N14685	T-A87560	Air Filter
N16533	T-FS3020	Air-Oil Separator
N17480	T-A8768060	Air Filter
N17534	T-A87460	Air Filter
N17535	T-A87460	Air Filter
N18661	T-A876860	Air Filter
N20661	T-FS8920	Air-Oil Separator
N25950	T-A87115760	Air Filter
N2639500	T-A876860	Air Filter
N2769500	T-FS450	Air-Oil Separator
N2785000	T-FS7530	Air-Oil Separator
N2853300	T-FS1750	Air-Oil Separator
N9349	T-FO3211080	Oil Filter
TS15	T-WS004	Oil-Water Separator
TS16	T-WS006	Oil-Water Separator
TS3	T-WS002	Oil-Water Separator
TS4	T-WS003	Oil-Water Separator
TS60	T-WS008	Oil-Water Separator