



CATALOGUE 2026

21.12.2025

O.E.M.code	TAURUS code	Description
200950121	T-FS920	Air-Oil Separator
201250111	T-FS1220	Air-Oil Separator
201250171	T-FS1820	Air-Oil Separator
201250181	T-FS2920	Air-Oil Separator
201250221	T-FS3020	Air-Oil Separator
2010102017	T-FS990174	Air-Oil Separator
2116010021	T-FS8920	Air-Oil Separator
2116010054	T-FS990177	Air-Oil Separator
2116010085	T-FS990368	Air-Oil Separator
2116010086	T-FS990369	Air-Oil Separator
2116010109	T-FSP03350	Air-Oil Separator
2116010149	T-FS990192	Air-Oil Separator
2116010153	T-FS990316	Air-Oil Separator
2116010154	T-FS990209	Air-Oil Separator
2116010160	T-FO32116880	Oil Filter
2116010166	T-FS990208	Air-Oil Separator
2116019895	T-FS990179	Air-Oil Separator
2116020014	T-FO3215380	Oil Filter
2116020051	T-FO32116980	Oil Filter
2116020054	T-FO3215280	Oil Filter
2116020074	T-FO32116980	Oil Filter
2605530030	T-FS990071	Air-Oil Separator
2605530180	T-FO3211080	Oil Filter
2607289921	T-FS990176	Air-Oil Separator
2607289961	T-FS990175	Air-Oil Separator
2608289970	T-FS990178	Air-Oil Separator
7115166010	T-A87114460	Air Filter
7118146930	T-FO3210980	Oil Filter
20120218031	T-FS990175	Air-Oil Separator
20120405020	T-FS990176	Air-Oil Separator
2009-50121	T-FS920	Air-Oil Separator
2010-102017	T-FS990174	Air-Oil Separator
2012-0218031	T-FS990175	Air-Oil Separator
2012-0405020	T-FS990176	Air-Oil Separator
2012-50111	T-FS1220	Air-Oil Separator
2012-50171	T-FS1820	Air-Oil Separator
2012-50181	T-FS2920	Air-Oil Separator
2012-50221	T-FS3020	Air-Oil Separator
2116010022	T-FS990082	Air-Oil Separator
2116010026	T-FS990076	Air-Oil Separator
2116010028	T-FS990077	Air-Oil Separator
2116010035	T-FS990078	Air-Oil Separator
2116010057	T-FS990077	Air-Oil Separator
2116010098	T-FSP03250	Air-Oil Separator
2116010105	T-FS990077	Air-Oil Separator
2116010132	T-FS990085	Air-Oil Separator
21160-10154	T-FS990209	Air-Oil Separator
2116010157	T-FS990402	Air-Oil Separator
2116010158	T-FS990077	Air-Oil Separator
2116010159	T-FS990076	Air-Oil Separator



CATALOGUE 2026

21.12.2025

2116010160	T-FS990403	Air-Oil Separator
2116010161	T-FS990179	Air-Oil Separator
21160-10166	T-FS990208	Air-Oil Separator
2116010215	T-FS990404	Air-Oil Separator
2116010223	T-FS990405	Air-Oil Separator
2116019889	T-FS990192	Air-Oil Separator
2116020053	T-FO3215380	Oil Filter
2116040176	T-A87131360	Air Filter
2116040194	T-A8772260	Air Filter
2605271160	T-FS990316	Air-Oil Separator
260553016	T-FO531005	Oil Filter
2605530160	T-FO32104380	Oil Filter
26055-30160	T-FO32104380	Oil Filter
2605530830	T-FO32104880	Oil Filter
2605539880	T-FO32115780	Oil Filter
2605703060	T-FO32104680	Oil Filter
26072-89921	T-FS990176	Air-Oil Separator
26072-89961	T-FS990175	Air-Oil Separator
2608-289970	T-FS990178	Air-Oil Separator
2655531450	T-FO32113280	Oil Filter
7111121146910B	T-FSP03350	Air-Oil Separator
7111211148100	T-FO3211080	Oil Filter
7111211148120	T-FO3215380	Oil Filter
7111221148120	T-FO3215280	Oil Filter
7112111148020	T-FO32116880	Oil Filter
71121111-48020	T-FO32116880	Oil Filter
7112111148120	T-FO32105680	Oil Filter
71121111-48120	T-FO32105680	Oil Filter
7112111148120A	T-FO3211080	Oil Filter
7112131146910	T-FS950	Air-Oil Separator
7115146950	T-FO531005	Oil Filter
71152-46910	T-FS950	Air-Oil Separator
7116111140820	T-FO32104880	Oil Filter
71161111-40820	T-FO32104880	Oil Filter
7116111148120A	T-FO32197980	Oil Filter
7118146930	T-FO3210980	Oil Filter
711823E1-26A43	T-FO32104680	Oil Filter
91101-020	T-FS920	Air-Oil Separator
91101-040	T-FS1220	Air-Oil Separator
91101-050	T-FS15320	Air-Oil Separator
91101-060	T-FS1820	Air-Oil Separator
91101-075	T-FS3020	Air-Oil Separator
91101-150	T-FS990084	Air-Oil Separator
91101-175	T-FS5520	Air-Oil Separator
91101-200	T-FS14720	Air-Oil Separator
91101-300	T-FS12920	Air-Oil Separator
91107-012	T-FO3211080	Oil Filter
91107032	T-FO3210980	Oil Filter
91107-032	T-FO3210980	Oil Filter
91107-082	T-FO32104380	Oil Filter
91108-012	T-FS550	Air-Oil Separator



CATALOGUE 2026

21.12.2025

91108-022	T-FS950	Air-Oil Separator
91108-042	T-FS450	Air-Oil Separator
91111-001	T-FS10220	Air-Oil Separator
91111-002	T-FS16720	Air-Oil Separator
91111-003	T-FS13420	Air-Oil Separator
91111-004	T-FS13820	Air-Oil Separator
91111-005	T-FS13220	Air-Oil Separator
91111-006	T-FS4320	Air-Oil Separator
91111-007	T-FS8920	Air-Oil Separator
91111-008	T-FS9020	Air-Oil Separator
94203-210	T-A87114460	Air Filter
94203-410	T-A87114560	Air Filter
94203420	T-A8767060	Air Filter
9610112-10650M	T-FS1220	Air-Oil Separator
961011220900M	T-FS2920	Air-Oil Separator
9610112-20900M	T-FS1820	Air-Oil Separator
9610112-20901M	T-FS990076	Air-Oil Separator
9610112-21601M	T-FS990083	Air-Oil Separator
961011221700M	T-FS2920	Air-Oil Separator
9610112-21700M	T-FS990084	Air-Oil Separator
9610112-21900M	T-FS990084	Air-Oil Separator
9610112-21901M	T-FS990076	Air-Oil Separator
9610112-22001M	T-FS13820	Air-Oil Separator
9610112-22201M	T-FS990081	Air-Oil Separator
9610112-22301M	T-FS990083	Air-Oil Separator
9610112-22500M	T-FS5520	Air-Oil Separator
9610112-22801M	T-FS990079	Air-Oil Separator
9610112-23000M	T-FS14720	Air-Oil Separator
9610112-23401M	T-FS990080	Air-Oil Separator
9610112-24001M	T-FS16720	Air-Oil Separator
9610112-24200M	T-FS12920	Air-Oil Separator
9610112-30450M	T-FS920	Air-Oil Separator
9610122-21871P	T-FS990083	Air-Oil Separator
9610122-21871-P	T-FS990083	Air-Oil Separator
9610153-28101	T-FS990368	Air-Oil Separator
9610153-28181P2	T-FS990369	Air-Oil Separator
9610153-28181-P2	T-FS990369	Air-Oil Separator
9610221-20330Z	T-FS5720	Air-Oil Separator
9610221-20400M1	T-FS990165	Air-Oil Separator
9610221-20550M1	T-FSP03250	Air-Oil Separator
9610311-20150M1	T-FO3222680	Oil Filter
9610311-20200M1	T-FO32104980	Oil Filter
9610512-N0450M1	T-A87114460	Air Filter
9610512-N0450P	T-A87131360	Air Filter
9610512N0800M1	T-A8767060	Air Filter
9610512-N0800M1	T-A87114560	Air Filter
9610512N0800P1	T-A8766660	Air Filter
9610512-N0800P1	T-A8766660	Air Filter
FF005C	T-M11946	In-Line Filter
FF005H	T-M11936	In-Line Filter
FF005U	T-M11926	In-Line Filter



CATALOGUE 2026

21.12.2025

FF010C	T-M11947	In-Line Filter
FF010H	T-M11937	In-Line Filter
FF010U	T-M11927	In-Line Filter
FF015C	T-M11948	In-Line Filter
FF015H	T-M11938	In-Line Filter
FF015U	T-M11928	In-Line Filter
FF030C	T-M11949	In-Line Filter
FF030H	T-M11939	In-Line Filter
FF030U	T-M11929	In-Line Filter
FF050C	T-M11950	In-Line Filter
FF050H	T-M11940	In-Line Filter
FF050U	T-M11930	In-Line Filter
FF075C	T-M11951	In-Line Filter
FF075H	T-M11941	In-Line Filter
FF075U	T-M11931	In-Line Filter
FF125C	T-M11952	In-Line Filter
FF125H	T-M11942	In-Line Filter
FF125U	T-M11932	In-Line Filter
FF175C	T-M11953	In-Line Filter
FF175H	T-M11943	In-Line Filter
FF175U	T-M11933	In-Line Filter
FF250C	T-M11954	In-Line Filter
FF250H	T-M11944	In-Line Filter
FF250U	T-M11934	In-Line Filter
FF300C	T-M11954	In-Line Filter
FF300H	T-M11944	In-Line Filter
FF300U	T-M11934	In-Line Filter
FF500C	T-M11955	In-Line Filter
FF500H	T-M11945	In-Line Filter
FF500U	T-M11935	In-Line Filter