



CATALOGUE 2026

21.12.2025

O.E.M.code	TAURUS code	Description
040.311	T-FS990106	Air-Oil Separator
040.320	T-A873860	Air Filter
040.337	T-FSP08710	Air-Oil Separator
040.360	T-FSP10410	Air-Oil Separator
040.428	T-A8716560	Air Filter
040.436	T-A873960	Air Filter
040.618	T-FSP08810	Air-Oil Separator
040.659	T-A872860	Air Filter
040.741	T-A87560	Air Filter
040.873	T-FO3211980	Oil Filter
040.907	T-A875360	Air Filter
040.923	T-FS990101	Air-Oil Separator
041.038	T-FO3214580	Oil Filter
041.041	T-FO32100380	Oil Filter
041.046	T-FS5710	Air-Oil Separator
041.047	T-FS6210	Air-Oil Separator
041.079	T-FS990107	Air-Oil Separator
041.129	T-FSP10410	Air-Oil Separator
041.160	T-FO32100480	Oil Filter
041.210	T-FO32100580	Oil Filter
041.211	T-FO32102580	Oil Filter
041.327	T-A873860	Air Filter
041.336	T-FO32100180	Oil Filter
041.336	T-FO3214380	Oil Filter
041.376	T-FO32100680	Oil Filter
041.392	T-FO32100780	Oil Filter
041.430	T-A872560	Air Filter
041.492	T-A87170 ³	Air Filter
041.500	T-A874260	Air Filter
041.508	T-FO32415080	Oil Filter
041.618	T-A87P00560	Air Filter
041.712	T-A8793360	Air Filter
041.748	T-A8768560	Air Filter
041.764	T-A8767160	Air Filter
041.779	T-A8766560	Air Filter
041.828	T-A87R02560 ³	Air Filter
041.852	T-A87R04260	Air Filter
041.859	T-A87P04260	Air Filter
041.883	T-FS620	Air-Oil Separator
041.896	T-FS13420	Air-Oil Separator
041.908	T-A87R00560	Air Filter
041.916	T-FS13420	Air-Oil Separator
041.924	T-FO32100880	Oil Filter
041.932	T-FO32100980	Oil Filter
041.947	T-A8767060	Air Filter
041.963	T-A8775360	Air Filter
041.971	T-FS18820	Air-Oil Separator
041.986	T-FS13420	Air-Oil Separator
042.002	T-FS212620	Air-Oil Separator
042.035	T-FS9020	Air-Oil Separator



CATALOGUE 2026

21.12.2025

042.058	T-FS10220	Air-Oil Separator
042.129	T-FS37820	Air-Oil Separator
042.144	T-A87125660	Air Filter
042.224	T-A8770560	Air Filter
042.240	T-FCV204	Air Filter Housing
042.263	T-FO32101580	Oil Filter
042.374	T-A874260	Air Filter
042.406	T-A8771560	Air Filter
042.410	T-FCV202	Air Filter Housing
042.411	T-A879160	Air Filter
042.412	T-A87P09160	Air Filter
042.415	T-FCV203	Air Filter Housing
042.417	T-FCV204	Air Filter Housing
042.418	T-A8712260	Air Filter
042.419	T-A87670	Air Filter
042.422	T-FCV205	Air Filter Housing
042.423	T-A8712060	Air Filter
042.424	T-A87P12060	Air Filter
042.427	T-FCV207	Air Filter Housing
042.428	T-A8765160	Air Filter
042.429	T-A87P65160	Air Filter
042.432	T-FCV208	Air Filter Housing
042.433	T-A879660	Air Filter
042.434	T-A8794360	Air Filter
042.437	T-FCV209	Air Filter Housing
042.439	T-FCV211	Air Filter Housing
042.440	T-A879560	Air Filter
042.441	T-A8789960	Air Filter
042.442	T-A87R09560 ³	Air Filter
042.444	T-FCV212	Air Filter Housing
042.452	T-A872560	Air Filter
042.453	T-A8793360	Air Filter
042.455	T-FCV206	Air Filter Housing
042.585	T-FS20920	Air-Oil Separator
042.750	T-FO32101080	Oil Filter
042.851	T-FS990299	Air-Oil Separator
042.856	T-FSP19220	Air-Oil Separator
043.192	T-A87127060	Air Filter
043.245	T-FS7220	Air-Oil Separator
043.284	T-A87106460	Air Filter
043.314	T-FS10420	Air-Oil Separator
043.317	T-FS10520	Air-Oil Separator
043.455	T-FO3210980	Oil Filter
043.494	T-A87127160	Air Filter
043.548	T-FS990287	Air-Oil Separator
043.581	T-FS33120	Air-Oil Separator
043.651	T-FS990288	Air-Oil Separator
337.843	T-Z9049	Air-Oil Separator
905.014	T-A87106660	Air Filter
905.245	T-FO32102380	Oil Filter
905253	T-FO3214580	Oil Filter



CATALOGUE 2026

21.12.2025

905276	T-A8715260	Air Filter
905558	T-FS450	Air-Oil Separator
042.405.001	T-FCV101	Air Filter Housing
042.410.001	T-FCV102	Air Filter Housing
042.415.001	T-FCV103	Air Filter Housing
042.417.001	T-FCV104	Air Filter Housing
042.422.001	T-FCV105	Air Filter Housing
042.427.001	T-FCV107	Air Filter Housing
042.432.001	T-FCV108	Air Filter Housing
042.437.001	T-FCV109	Air Filter Housing
042.439.001	T-FCV111	Air Filter Housing
042.444.001	T-FCV112	Air Filter Housing
042.446.001	T-FCV113	Air Filter Housing
042.455.001	T-FCV106	Air Filter Housing
CF1	T-A87245360	Air Filter
CF4	T-A87245460	Air Filter
CF5	T-A87245560	Air Filter
CF6	T-A87245660	Air Filter
CF8	T-A87245760	Air Filter
CF9	T-A87245860	Air Filter
CL5	T-A873860	Air Filter
CL6	T-A872060	Air Filter
CL8	T-A872260	Air Filter
CL9	T-A8715260	Air Filter
FL1	T-FB40	Air Filter Housing
FL2	T-FB41	Air Filter Housing
FL3	T-FB42	Air Filter Housing
FL4	T-FB43	Air Filter Housing
FL5	T-FB44	Air Filter Housing
FL6	T-FB45	Air Filter Housing
FL8	T-FB46	Air Filter Housing
FL9	T-FB47	Air Filter Housing
SI4	T-SS13	Silencer two connections
SI5	T-SS14	Silencer two connections
SI6	T-SS15	Silencer two connections
SI8	T-SS17	Silencer two connections
SS4	T-SS4	Silencer one connections
SS5	T-SS5	Silencer one connections
SS6	T-SS6	Silencer one connections